QC-800

FVW

PIONEER



HEAD AMP UNIT

AWF - 002



CONTROL AMP UNIT

AWG - 002



Q UNIT
AWM-001



QC-800



SWITCHES

- S_1 INPUT SELECTOR
  1. PHONO 1
  2. PHONO 2
  3. TUNER
  4. AUX 1
  5. AUX 2
- S_2 MODE SELECTOR
  1. 2CH. STEREO
  2. QUADRALIZER
  3. 4CH. STEREO
  4. L (CH.1) MONO
  5. R (CH.3) MONO
- S_3, S_4 BASS CONTROL -9dB ~ +12dB
- S_5, S_6 TREBLE CONTROL -12dB ~ +9dB
- S_7 TAPE MONITOR 1 OFF-ON
- S_8 TAPE MONITOR 2 OFF-ON
- S_9 QUADRALIZER
  1. MATRIX
  2. PHASE SHIFT
- S_{10} LOW FILTER OFF-ON
- S_{11} HIGH FILTER OFF-ON
- S_{12} OUTPUT ON-OFF
- S_{13} MUTING 0dB ~ -20dB
- S_{14} POWER OFF-ON
- S_{15} LINE VOLTAGE SELECTOR

POTENTIOMETERS

- VR_1 LEVEL CONTROL (CH. 1)
- VR_2 LEVEL CONTROL (CH. 3)
- VR_3 LEVEL CONTROL (CH. 2)
- VR_4 LEVEL CONTROL (CH. 4)
- VR_5 VOLUME CONTROL

RESISTORS
NON MARK : OHM
K : KILOHM
M : MEGOHM

CAPACITORS
NON MARK : μF
P : μμF

V : SIGNAL VOLTAGE
V : DC VOLTAGE AT NO INPUT SIGNAL
⇨ : DC CURRENT AT NO INPUT SIGNAL

0.3A : 110V, 120V, 130V
0.2A : 220V, 240V

Q UNIT

AWM-001